Sash Balance Installation

Type D4 and D6 - Standard Type AL - Assisted Lift





It is recommended that the sashes are glazed and painted to ensure both sashes slide freely in the frame.


Preparation of Windows


Grooves to house balances can be in either frame jambs or in sash stiles, rounded or square and must be of minimum dimensions shown (Figs 1 & 2).


Bottom of sashes should be prepared to suit balance foot attachment to be used. Cut-outs should be sufficient depth to receive attachments and screw heads.












Checking balances

It is important that the balances used are suitable for the weight of the sash. They are manufactured in weight groups that are identified by a colour. (See Fig. 7).



D4 Up to 13.6kg (30lb)

D6 13.6kg (30lb) - 18.1kg (40lb)